



## SnapMirror transfer stuck at 0 bytes and "volume show" take long time to execute

[https://kb-stage.netapp.com/on-prem/ontap/DP/SnapMirror/SnapMirror-KBs/SnapMirror\\_transfer\\_stuck...](https://kb-stage.netapp.com/on-prem/ontap/DP/SnapMirror/SnapMirror-KBs/SnapMirror_transfer_stuck...)

Updated: Wed, 24 Jun 2026 07:24:41 GMT

### Applies to

- ONTAP 9
- SnapMirror
- FAS 8200

### Issue

- SnapMirror transfer stuck at 0 bytes
- The volume show execution takes a very long time to complete on the SnapMirror destination volume
- Rebooting both nodes does not solve the problem

- After re-initializing the destination cluster system, the Cluster Setup process takes more than 20 minutes to complete.
- The DP volume fails to be offlined and deleted