



how many ports is activated by default for switch BES-53248

https://kb-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/how_many_ports_is_activated_by_default...

Updated: Wed, 24 Jun 2026 07:24:34 GMT

Applies to

Switch BES-53248

Answer

- The BES-53248 comes configured by default with 16 x 10/25GbE (SFP+/SFP28) ports and 2 x 40/100GbE (QSFP+/QSFP28) ports activated.
- Port 1-16 and 55-56 is activated by default.
- Check port status use command # `show port all` in switch command line .

Additional Information

[how many ports is activated by default for switch BES-53248](#)