



## RPANIC:page fault (supervisor read data, page not present) 0xffffffff8a0a3693

[https://kb-stage.netapp.com/on-prem/ontap/Ontap\\_OS/OS-KBs/RPANIC\\_page\\_fault\\_supervisor\\_read\\_...](https://kb-stage.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/RPANIC_page_fault_supervisor_read_...)

Updated: Wed, 24 Jun 2026 06:32:11 GMT

### Applies to

- ONTAP 9.13.1RC1
- SnapMirror
- SVM DR

### Issue

The system panics with the following panic string:

```
RPANIC:page fault (supervisor read data, page not present) on VA 0xd0 cs:rip  
0x20:0xffffffff8a0a3693 rflags 0x10297 in SK process snapd_cmode on release  
9.13.1RC1 (C)
```