



Workload Security External Engine repeatedly disconnecting and reconnecting

https://kb-stage.netapp.com/on-prem/ontap/da/NAS/NAS-KBs/Workload_Security_External_Engine_re...

Updated: Wed, 22 Apr 2026 02:10:29 GMT

Applies to

- ONTAP
- Workload Security
- Fpolicy

Issue

Workload Security External Engine is repeatedly disconnecting and reconnecting with error
`fpolicy.server.disconnect:error]: Connection to the FPolicy server "x.x.x.x" of policy "<policy name>" is broken for Vserver <verver name>`