



## FAS70 new setup PANIC : sk\_cycles\_per\_msec 800000

[https://kb-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/FAS70\\_new\\_setup\\_PANIC\\_\\_\\_sk\\_cycles\\_...](https://kb-stage.netapp.com/on-prem/ontap/OHW/OHW-KBs/FAS70_new_setup_PANIC___sk_cycles_...)

Updated: Wed, 22 Apr 2026 02:10:10 GMT

### Applies to

FAS70

### Issue

New setup node will not boot ONTAP or maintenance mode, the following panic is observed:

```
PANIC : sk_cycles_per_msec 800000: start 0, end 0, ontap_freq 800000155
```