



---

## View drive encryption status StorageGRID Appliances equipped with BMC

[https://kb-stage.netapp.com/hybrid/StorageGRID/Maintenance/View\\_drive\\_encryption\\_status\\_Storage...](https://kb-stage.netapp.com/hybrid/StorageGRID/Maintenance/View_drive_encryption_status_Storage...)

Updated: Wed, 22 Apr 2026 02:10:15 GMT

### Applies to

[StorageGRID Appliances\(SGA\) that contains BMC](#)

### Description

This procedure covers the process on how to view SED drive encryption status