



---

## volumes in nvfail state after Mediator assisted unplanned switchover

[https://kb-stage.netapp.com/on-prem/ontap/mc/MC-KBs/volumes\\_in\\_nvfail\\_state\\_after\\_Mediator\\_assist...](https://kb-stage.netapp.com/on-prem/ontap/mc/MC-KBs/volumes_in_nvfail_state_after_Mediator_assist...)

Updated: Wed, 22 Apr 2026 02:10:22 GMT

### Applies to

- MetroCluster IP
- Mediator Assisted Unplanned Switchover (MAUSO)

### Issue

A power issue or disaster may result in volumes being in nvfail state after mediator assisted unplanned switchover (MAUSO)

EMS Log:

```
waf1.vol.setting.in.nvfailed.state:error]: Volume volume@vserver:12345 is marked as in-nvfailed-state: NVPM copy failed.
```

