



Disk auto assigned to the wrong pool and owner in a MetroCluster

https://kb-stage.netapp.com/on-prem/ontap/mc/MC-KBs/Disk_auto_assigned_to_the_wrong_pool_and...

Updated: Wed, 24 Jun 2026 08:16:19 GMT

Applies to

- ONTAP 9
- MetroCluster
- Disk replacement

Issue

Newly replaced drive auto assigned to the wrong pool and owner:

```
Wed Apr 08 09:17:46 UTC [nodeA: dmgr_thread: raid.disk.inserted:info]: Disk 3b.125L517 Shelf 11 Bay 16 [NETAPP X438_S1633400AMD NA01] S/N [S20XXXX] UID [5002538A:758137E0:00000000:00000000:00000000:00000000] has been inserted into the system
```

Wed Apr 08 09:17:46 UTC [nodeA: config_check: config.BadPoolAssign:error]: Disk 1.11.16 is in Pool0 and other disks on this loop/domain are in Pool1. Disks/interfaces need to be in separate pools for SyncMirror.