



What does the alert "Usable Space Less Than 60%" mean?

https://kb-stage.netapp.com/?title=on-prem/solidfire/Element_OS_Kbs/What_does_the_alert_%22Usab...

Updated: Wed, 24 Jun 2026 07:24:39 GMT

Applies to

- SolidFire Element OS
- HCI Storage Element OS
- NetApp SolidFire Active IQ (Active IQ)

Answer

- This alert defines on Active IQ as following policy:

WARNING	Usable Space Less Than 60%
ERROR	Usable Space Less Than 40%

CRITICAL Usable Space Less Than 20%

- The alert reports on Active IQ if the usable space of cluster block capacity less than above threshold.

Example Message:

Status: New Alert Notification

Alert ID: 406c5df2-e31e-4e11-81fd-7202e73540f6

Alert Policy: Usable Space Less Than 60%

Severity: Warning

Cluster: xxxxxx

Occurrence Time: 2020-03-03 11:55:31 UTC

Notification Time: 2020-03-03 11:55:31 UTC

Additional Detail:

- unusedSpacePercent: 59.9% unused
- usedSpace: 33,845,681,141,416 bytes
- maxUsedSpace: 84,497,346,920,448 bytes

Historical Detail: This alert has occurred 1 times in the last 30 days.

Alerts for this Cluster

- This alert indicates the current usage of block capacity and has no impact on the cluster.

- **Additional Information**

Add your text here.