



---

## High latency seen when using volume move in foreground

[https://kb-stage.netapp.com/on-prem/ontap/Perf/Perf-KBs/High\\_latency\\_seen\\_when\\_using\\_volume\\_m...](https://kb-stage.netapp.com/on-prem/ontap/Perf/Perf-KBs/High_latency_seen_when_using_volume_m...)

Updated: Wed, 22 Apr 2026 02:10:23 GMT

### Applies to

- ONTAP 9
- Volume move

### Issue

- Using the command `volume move start` with the parameter `-foreground true`.
- Increased latency may be seen from Data (CPU D-Blade) and/or Disk from the command `qos statistics volume latency show`.
- **Example:** This output shows higher than usual Data latency or Disk latency from the command `qos statistics volume latency show`.

```

Cluster::> qos statistics volume latency show
Workload          ID      Latency      Network      Cluster
Data             Disk      QoS        NVRAM        Cloud
-----
-----
-total-          -      8.88ms      2.82ms      1.00us      1032.
00us           5.02ms      0ms        2.00us      0ms
citrix_home1-.. 6762     137.73ms   1.91ms      1.00us      22.93ms
112.89ms      0ms        0ms        0ms

```