



---

## Stale LIF placement warning in metrocluster check

[https://kb-stage.netapp.com/on-prem/ontap/mc/MC-KBs/Stale\\_LIF\\_placement\\_warning\\_in\\_metrocluste...](https://kb-stage.netapp.com/on-prem/ontap/mc/MC-KBs/Stale_LIF_placement_warning_in_metrocluste...)

Updated: Wed, 22 Apr 2026 02:10:25 GMT

### Applies to

- MetroCluster
- ONTAP 9

### Issue

- Warning on LIFs when executing `metrocluster check show` :

**Example:**

```
clusterA::> metrocluster check show
Component Result
-----
```

```
nodes ok
lifs warning
config-replication ok
aggregates ok
clusters ok
5 entries were displayed.
```

- `metrocluster check lif show` displays no errors:

**Example:**

```
clusterA::> metrocluster check lif show
```

Cluster	Vserver	LIF	Check	Result
ClusterA	svm1-mc	LIF1	lif-placed-on-dr-node port-selection	ok ok
ClusterB	svm1	LIF1	lif-placed-on-dr-node port-selection	ok ok