



## Cannot add ONTAP cluster to AIQUM due to incorrect LIF role

[https://kb-stage.netapp.com/data-mgmt/AIQUM/AIQUM\\_Kbs/Cannot\\_add\\_ONTAP\\_cluster\\_to\\_AIQUM\\_...](https://kb-stage.netapp.com/data-mgmt/AIQUM/AIQUM_Kbs/Cannot_add_ONTAP_cluster_to_AIQUM_...)

Updated: Wed, 24 Jun 2026 08:16:00 GMT

### Applies to

- ActiveIQ Unified Manager (AIQUM) 9.6+
- ONTAP 9

### Issue

- Adding ONTAP cluster to AIQUM fails
- `ocumserver.log`:  
`Unable to contact the host" & "Server returned HTTP status 500`
- ONTAP LIF used has role `node-mgmt`.  
Example:  

```
:> network interface show -lif <lif> -fields role
```

```
vserver    lif        role
-----
cluster1  <lif>     node-mgmt
```

- Cluster has no LIF with role `cluster-mgmt`